




## INSTRUCTION MANUAL



22" FIRE PIT WITH LOG RACK JS-FT168

---

Thank you for your purchase.  
Please contact us if you have difficulty with assembly  
or need replacement parts.  
Vingli Customer Service team is here to assist you.  
Here is how we can connect:  
Email: [support@bonnlo.com](mailto:support@bonnlo.com)

### Special Warnings

- Check local bylaws before using the fire pit.
- This fire pit is intended for Outdoor Use Only! DO NOT use on wooden decks.
- This fire pit is intended to burn Wood Logs Only! DO NOT burn coal, leaves or other combustible materials in the fire pit.
- NOT for use by children. Keep children and pets away from the fire pit.
- Fire pit is hot, use with caution. NEVER touch hot fire pit with bare hands.
- NEVER leave burning fire pit unattended and always extinguish fire completely before leaving the fire pit.
- Keep the fire pit at least 20 feet away from any flammable surface or dwelling.
- DO NOT use near flammable or combustible objects or materials.
- Only CHROMED PLATED COOKING GRID is intended for cooking. LOG GRATE is NOT intended for cooking and SHOULD NOT be used for this purpose.
- Always use gloves and protective glasses when loading the fire pit or extinguishing the fire.
- Have a fire extinguisher available near the fire pit in case of emergency.

### Operation Instructions

- Place wood logs on grate and light with match. DO NOT overload logs.
- Please use Poker (provided) when handling.
- We do not recommend pouring water over the fire unless necessary. The fire should be allowed to expire on its own.

### Care and Maintenance

This fire pit is a quality-built product and is made to last for many years. The frame structure of this unit is made of powder-coated steel extrusion and should resist rusting under normal use. Should rusting occur, we suggest using a steel brush on the affected area followed by a spray coating of high temperature anti-rust paint. For additional rust proofing of the bowl, grate and mesh lid we recommend that a coat of high temperature primer is applied **before** use.

## Parts List

Please check all packing material carefully before discarding, as some parts may be encased in the packing material.

Part List	Description	Qty.	Drawings
A	Fire Bowl	1	
B	Legs	4	
C	Mesh Lid	1	
D	Rack	1	
E	Ring	1	
F	Log Grate	1	
G	Lid Ring with Nut	1	
H	Bolts(M6X8MM)	12	
I	Nut	8	
J	Poker	1	
K	Allen Wrench	1	

Tool required: Allen Wrench (provided)

## Assembly Instruction

Estimated Assembly Time: 10 Minutes

Please fully tighten the screws & nuts to ensure the stability.

### Step 1

Attach Rack (D) to Legs (B) by using Bolts(H) and Nuts(I). Please fully tighten at this point. (View Fig.1) .




fig.1

### Step 2

Attach Ring (E) to Legs (B) with Bolts (H). Tighten all bolts by Allen Wrench (K)(View Fig.2).




fig.2

### Step 3

Put Log Grate(F) on Fire Bowl (A) and then put it on the fire pit base after step 2. Screw Lid Ring (G) to the Mesh Lid (C). Then place the Mesh Lid (C) on the Fire Bowl(A). (View Fig.3).




fig.3



**WARNING!**

- The use of alcohol, prescription or non-prescription drugs may impair the ability to properly assemble or safely operate this fire pit.
- When using this fire pit, exercise the same precautions you would with any open fire.
- Do not use this fire pit for indoor heating. Toxic carbon monoxide fumes can accumulate and cause asphyxiation or death.